



How to check the battery


1. You can see your battery status in the bottom right hand corner of the screen at any time.




2. To see more detail touch the battery and see the status % of the battery.




3. To see more details about the battery touch and open the settings menu



4. Scroll down to the **Device** section and touch on **Battery**.



5. You will see the battery information.



Creative Commons, Attribution, Non-Commercial, Share Alike (South Africa)
ICT4RED (<http://ict4red.blogspot.com>)
Tutorial creator: Maggie Verster